
gorenje⁺

User manual

GGC31W

GGC32

GGC64



GB

Manual

GB 3 - GB 22

Pictograms used



Important information



Tip

CONTENTS

Your gas hob

Introduction	4
Description	5

Safety

What you should pay attention to	6
Safe use	6
Children	7

Controls

Igniting and adjusting	8
Flame failure device	8

Comfortable cooking

Optimal use of the hob	9
Wok burner	9

Maintenance

General	10
Cleaning	11

Faults

Faults table	12
--------------	----

Installation

General	14
Gas connection	14
Electrical connection	14
Building in	15
Technical data	21

Environmental aspects

Disposal of package and appliance	22
-----------------------------------	----

Introduction

This gas hob has been designed for the true cooking enthusiast. The differences in burner capacity allow you to cook any type of dish. The control buttons have an integrated spark ignition, which means that you need only one hand to ignite and operate the burners.

The gas hob is fitted with a flame failure device, which ensures that the gas supply is shut off if the flame goes out during the cooking process.

This manual explains optimum use of the gas hob. In addition to information on operation, you will also find background information that may be useful to you when using this product.

Read the manual thoroughly before using the appliance, and store these instructions in a safe place for future reference.

The manual also serves as reference material for service technicians.


Please, therefore, stick the appliance identification card in the space provided, at the back of the manual. The appliance identification card contains all the information that the service technician will need in order to respond appropriately to your needs and questions.

Enjoy your cooking!


YOUR GAS HOB

Description


GGC31W...



GGC32...



GGC64...



1. Wok burner

2. Semi-rapid burner

3. Simmer burner

4. Rapid burner

5. Pan support wok

6. Pan support

7. Glass panel

What you should pay attention to



- Ensure that there is adequate ventilation during use. Keep natural ventilation openings open.
- When using the hob for long periods, extra ventilation is necessary. Open a window for instance or install a mechanical fan.
- Use the hob only for preparing dishes. The appliance is not suitable for space heating.
- Never flambé under an extractor hood. The high flames can cause a fire, even if the fan is switched off.
- The burner parts are hot during and immediately after use. Do not touch them, and avoid contact with non-heat-resistant materials.
- Never immerse hot burner parts in cold water. The rapid cooling can damage the enamel.
- The distance from the pan to a knob or non-heat-resistant wall should always be greater than two centimetres. In case of smaller distances the high temperature may cause the knobs or wall to discolour and/or distort.
- Always use the pan supports and suitable cooking utensils.
- Always place the pan on the pan support. Placing the pan directly on the burner head can result in dangerous situations.
- Aluminium trays or foil are not suitable as cooking utensils. They can become burnt into the burners and pan supports.
- The hob can only function effectively if the burner parts have been assembled using the guide ridges.
- Ensure that the pan supports lie properly against each other and flat on the glaa panel. Only then can the pans be positioned stably.

Safe use



- The device will become hot during use and will remain so for some time after it has been switched off. So please be sure not to touch the device while it is hot.
- Always wear oven gloves or use oven cloths when operating the device. Keep oven gloves or oven cloths away from the flame.
- Do not warm closed tins and such like on the hob. There will be a buildup of pressure that will cause tins to explode. You might get injured or scalded.
- The device is not to be positioned nor used outdoors.

SAFETY


- Do not use the device as a worktop. The device may be switched on by accident or still be hot, which means objects could melt, become hot or catch fire.
- Never cover the device with a cloth or something similar. If the device is still hot or is switched on, there is a risk of fire.
- Be extra careful when using oils or fats. Overheated oil or fats may catch fire. Risk of fire!
- Under no circumstances should you use water to try and extinguish the flames if the oil or fat were to catch fire! Extinguish the flames with a suitable lid, a damp cloth or some such object.
- If there is a drawer underneath the device, without an intermediate bottom, this should not be used to store highly flammable objects/ materials.
- Never use a pressure cleaner or a steam cleaner to clean the device. This could cause a short circuit.

Children



- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Never let children play with this device. Children are not to be allowed near the device unsupervised.
- The device will become hot during use and will remain hot for some time after it has been switched off.
- Do not keep objects in cupboards above or behind the device that children might find interesting.
- Children may sustain burns when they pull pots or pans off the device. A special frame that stops children from getting close to the device is available from the specialist dealer.
- If the safety instructions and warnings are not heeded, the manufacturer can not be held liable for any consequential damage.

Igniting and adjusting



1. *Burner indication*
2. *0-setting*
3. *High setting*
4. *Simmer setting*

A symbol near the control knob indicates which burner is being controlled. The burners can be adjusted continuously between the high and low positions.

Flame failure device

Your gas hob has a flame failure device. This ensures that the gas supply is shut off if the flame goes out during cooking.

Operating the thermal flame failure device

Press the control knob and turn it anti-clockwise. Hold the control knob pressed for approximately 3 seconds after the burner has ignited.

The flame failure device switches on.

When the burner does not ignite, check whether:


- the burner cap is placed on top of the burner correctly;
- the burner/spark plug is clean and dry.

COMFORTABLE COOKING

Optimal use of the hob



Wrong



Right

Always ensure that the flames remain below the pan. If flames play around the pan, a lot of energy is lost. In addition, the handles can get too hot. Do not use pans with a base diameter less than 12 cm. Smaller pans will not be stable.




- When frying, stir-frying, heating through large quantities and deepfrying it is best to use the rapid or wok burner.
- Preparing sauces, simmering and boiling can be done best on the simmer burner. On its high setting this burner is large enough for cooking food right through.
- Cook with the lid on the pan. This way you save up to 50% energy.
- Use pans with a flat, clean, dry base. Pans with a flat base stand stably and pans with a clean base transfer the heat more effectively to the food.

Wok burner (GCC31W...)

With the wok burner you can prepare dishes at a very high temperature. For this purpose it is important:

- to cut the ingredients into strips, slices or pieces before cooking;
- to use good-quality oil, such as olive, maize, sunflower or peanut oil when stir-frying. A small quantity is enough. Butter and margarine on the other hand will burn because of the high heat;
- to place the dishes with the longest cooking time in the pan first, so that at the end of the cooking time all ingredients are cooked al dente at the same time.



The auxiliary support supplied for the wok burner or available as an accessory provides additional stability in case of a wok with a round base. The support can be obtained as an accessory: GWR470.


MAINTENANCE

General

Your appliance has been manufactured from high-grade materials, which are easy for you to clean.

- Regular cleaning immediately after use prevents over-cooked food being able to become ingrained and cause stubborn stains that are difficult to remove. Use a mild cleaning agent.
- Clean the control knobs, burners and pan supports first and then the glass panel. This avoids the glass panel getting dirty again during cleaning.
- Clean the spark plugs preferably with a cloth. Do this carefully. the spark plug can become defective. The sparkplug will only operate correctly in a dry environment. If the plug is very dirty, you may clean the point with a tiny brush.


Set the pan supports down vertically, without sliding them over the glass panel. Fit the pan supports over the 'beam'.



- Assemble the burner parts with the aid of the guide ridges, paying attention to the cut-out sections in the burner head for the spark-plug and thermocouple. Make sure that the burner parts lie flat.

Wok burner

1. External burner head
2. Internal burner head
3. Gas base
4. Burner base
5. Spark plug
6. Thermo couple



Simmer, semi-rapid and rapid burner

1. Burner head
2. Burner base
3. Spark plug
4. Thermo couple

Cleaning

Do not clean the pan supports in the dishwasher. The enamel on the pan supports is suitable for cleaning by dishwasher. However, the connection with the rubber feet is not. Moreover, the pan supports might show some discoloration if they were washed in the dishwasher. If the rubber feet are lost, the pan support is likely to damage the glass panel.

Remove with a non-abrasive cream. Never use scouring powder, scouring pads, sharp objects or aggressive cleansing agents.

Burner parts should not be cleaned in the dishwasher. The parts may be damaged by the dishwasher detergent! The removable burner components (including wok) are best cleaned with a mild cleaning product and a soft cloth. In the case of obstinate stains you can soak the parts in hot suds. Never use scouring powder, scouring pads, sharp objects or aggressive cleansing agents.

A few parts of the work burner are made from brass. It is normal for the colour of the brass to change as a result of the high temperatures that occur when cooking with a wok.

Clean the glass hob with a cleansing agent intended specifically for ceramic hobs. Water stains or limescale are most easily cleaned using a non-abrasive limescale remover.

The burner bases have a unique Keradur® surface coating. The special dirt-repelling lacquer has a ceramic filling which makes cleaning easier and substantially improves the durability of the burners. The burner bases are best cleaned with a mild cleaning product and a soft cloth.

FAULTS

Faults table

If the appliance does not work properly, this does not always mean that it is defective. Try to deal with the problem yourself first by checking the points mentioned below in the table.

<i>Fault</i>	<i>Cause</i>	<i>Solution</i>
There is a smell of gas in the vicinity of the appliance.	The gas connection of the gas hob is leaking.	Close the main gas tap. Contact your gas fitter.
A burner does not ignite.	Plug not in socket.	Push the plug into the socket.
	Fuse defective/fuse in meter cabinet switched off.	Fit a new fuse or switch the automatic fuse back on.
	Sparkplug dirty/damp.	Clean and dry the sparkplug.
	Burner parts not correctly installed.	Assemble the burner parts using the centring ridges.
	Burner parts dirty/damp.	Clean and dry the burner parts, making sure that the outflow holes are open.
	Main gas tap closed.	Open the main gas tap.
	Fault in the gas network.	Check with your gas supplier.
	Gas bottle or tank is empty.	Connect a new gas bottle or have the tank filled.
	Wrong type of gas used.	Check that the gas used is suitable for the appliance. If not, contact your gas fitter.
Control knob not kept pressed in far enough	Keep the control knob pressed in far enough between full and low. At first use this can take some more time because of the gas supply.	

FAULTS

<i>Fault</i>	<i>Cause</i>	<i>Solution</i>
The burner does not burn evenly.	Burner parts incorrectly installed.	Assemble the burner parts using the centring ridges.
	Burner parts dirty or damp.	Clean and dry the burner parts, making sure that the outflow holes are open.
	Wrong type of gas used.	Check that the gas used is suitable for the appliance. If not, contact your gas fitter.
The burner goes out after igniting.	Control knob not kept pressed in long enough.	Keep the control knob pressed in for at least 5 seconds.

INSTALLATION

General

This appliance should only be connected up by a registered installer! The gas and electrical connection must comply with national and local regulations.



Warning!

The type of gas and the country for which the appliance has been designed are indicated on the application identification card.

This is a category 3 appliance.

Gas connection

- We recommend that the hob be connected by means of a fixed pipe. Connection using a specially designed safety hose is also permitted.
- Behind an oven use must be made of a pipe made entirely out of metal.



Warning!

- A safety hose may not be bent and must not come into contact with moving parts of kitchen units.
- In all cases the connection tap for the appliance must be positioned such that it is easily accessible.

Before using the appliance for the first time check the connections using water and washing-up liquid to ensure that there are no gas leaks.

Electrical connection

230V - 50Hz - 0.6 VA

- Wall socket and plug must be accessible at all times.
- Electrical leads and cables should not be allowed to touch the hob.
- If you want to make a fixed connection, ensure that a multi-pole switch with a distance between contacts of 3 mm is installed in the supply cable.
- Do not use an adapter or an extension lead to connect the device to the electrical mains. Safe use of the device cannot be guaranteed with these accessories.
-

INSTALLATION



Warning!

This appliance must be earthed.

Installation, maintenance or repairs should only be carried out by professionals who are authorized by the manufacturer, as failure to do so will void the warranty.

The device should be disconnected from the mains prior to installation, maintenance or repairs. The device is only disconnected from the electric power if:

- the main switch of the electrical wiring/installation in the house is switched off, or
- the fuse for the electrical wiring/installation in the house has been completely removed, or
- the plug has been pulled out of the socket.

Faulty parts may only be replaced by original Gorenje+ parts. Only those parts are guaranteed by Gorenje+ to meet the safety requirements.


If the connecting cable is damaged, it may only be replaced by the manufacturer, the manufacturer's service organisation or equivalently qualified persons, in order to avoid dangerous situations.

Building in

Preparing the hob

Fit the elbow supplied on the appliance's gas connection.

1. 1/2" ISO 228 (straight)
2. 1/2" ISO 10226-1
(conical)
3. Sealing ring
4. Pipe adapter for
liquid gas (Depending
on the country-specific
connection regulations.)




INSTALLATION

Cut opening in worktop


- Saw the opening in the worktop. This should be done very accurately (see building in dimensions on page 17).
- If the woodtop is made of treated wood, then coat the sawn surfaces of the top with sealing varnish, to prevent moisture causing the top to swell.

Attachment points for mounting brackets


See 1* in the illustrations of dimensions for building in from page 17 onwards for the attachment points for mounting brackets.



Screw hole
for mounting bracket




Thin worktops



Thick worktops


Placing the sealing tape

Remove the protective foil of the sealing strip (A) and attach the sealing strip in the groove of the aluminium profiles or the edge of the glass plate. Do not attach the sealing strip through the corner. Instead, cut 4 pieces that fit tightly together in the corners.





INSTALLATION

Building in dimensions GGC64...




Minimum distance between rear of appliance and rear wall: 10 mm





INSTALLATION

GGC31W...




Minimum distance between rear of appliance and rear wall: 10 mm



INSTALLATION

Building in dimensions opening worktop for GGC32...




			
x	490	490	490
y	290	620	950

Use the coupling profiles provided when the units are fitted tightly together. Keep an edge of minimum 60 cm between the holes if the coupler is not used.

INSTALLATION

Space to be left free around the appliance

A hob generates heat. Leave a sufficient distance between the appliance and non heat-resistant materials. Take care also with materials that may discolour (such as stainless steel).



The gas hob may only be built in next to one wall.



Caution!

The bottom of the hob becomes hot. Do not place combustible items in a drawer if the drawer is fitted directly below the hob.

Install appliance and make connections

- Place the appliance in the worktop and secure it using the mounting brackets and screws supplied.
- Connect to the gas supply.
- Check with soap suds that the connection is gastight.
- Connect the appliance to mains electricity.

Technical data

On the label on the bottom of this equipment, you will find the total wattage, the required voltage and the frequency.

Gas information

	<i>Simmer</i> (kW / g/h)	<i>Semi-rapid</i> (kW / g/h)	<i>Rapid</i> (kW / g/h)	<i>Wok</i> (kW / g/h)
<i>G20/20 mbar</i>	1.00 / -	2.00 / -	3.00 / -	4.50 / -
<i>G20/13 mbar</i>	1.00 / -	1.90 / -	2.50 / -	4.10 / -
<i>G30/28-30 mbar</i>	0.90 / 65	1.60 / 115	2.30 / 166	3.50 / 252
<i>G30/50 mbar</i>	1.00 / 72	2.00 / 144	2.70 / 194	4.00 / 288
<i>G31/67 mbar</i>	1.00 / 72	2.00 / 144	2.70 / 194	4.00 / 288
<i>G110/8 mbar</i>	1.00 / -	1.90 / -	2.60 / -	3.55 / -

When adapting the appliance for use with another type of gas, see conversion set manuals and use specified conversion set.

Burner power is indicated by observing the upper Hs caloric value.

Warning: these tasks may only be carried out by a qualified technician, authorized by the gas distributing company or authorized service center!

Disposal of packaging and appliance

In the manufacturing of this appliance durable materials were used. Make sure to dispose of this equipment responsibly at the end of its lifecycle. Ask the authorities for more information regarding this.

The appliance packaging is recyclable. The following may have been used:

- cardboard;
- polythene film (PE);
- CFC-free polystyrene (PS hard foam).

Dispose of these materials in a responsible manner and in accordance with government regulations.




As a reminder of the need to dispose of household appliances separately, the product is marked with the symbol of a crossed-out wheeled dustbin. This means that at the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources.



326309





gorenje⁺

